Public Address System

Touch Screen Wire Control Terminal

DP800F



User Manual

Thank you for using our DSPPA product. Please read the User Manual carefully before better use of the product.

Guangzhou DSPPA Audio Co.,Ltd

Http: //www. dsppatech.com /www.dsppacs.com

Content

I. Product Description 1

II. Features 1

III. Specification 1

IV. Connection Diagram 2

I. Product Description

DP800F is a fast and convenient function accessory in the DP series. It has a 4" IPS capacitive touch screen with functions of quick recall of preset archives, total volume adjustment, and channel gain adjustment, and can be fixed in a 86 box, suitable for various occasions.

II. Features


- **Master volume adjustment**
- **Support each input and output volume adjustment**
- **Support scene recall function**
- **4" screen, no operation system**
- **Resolution ratio:480*480**
- **RS485 interface**
- **Dimension 90.7x90.7x27.9mm**

III. Specification

Model	DP800F
Size	4 inch
Resolution	480*480
Color	65K, 16-bit RGB
Voltage	9-18V
Communication Port	RS485
Effective Screen Size	L×W=71.9mm × 70.2mm
Dimension	L×W×H=90.7mm × 90.7mm × 27.9mm
Working Temperature	-20~70℃

IV. Connection Diagram





Notice

- When the power switch of this equipment is in the "off" state, the machine is not disconnected from the power grid. For safety reasons, please unplug the power cord from the power grid socket when the equipment is not in use.
- This equipment must not be exposed to water droplets or splashes and objects such as vases filled with water must not be placed on the equipment.
- Do not open the cover of the machine at will for fear of electric shock. Repairs must be performed by professionals with professional certificates when necessary.
- The terminals marked with symbols ϟ in the equipment indicate dangerous live electricity, and the operation of connecting these terminals must be done by trained personnel.
- This device is connected to the power grid through a power cord plug.When the device goes wrong and become dangerous, you can disconnect the device from the power grid by unplugging the power cord. Therefore, it is required to place the power socket where it is in a convenient way for plugging and unplugging the power cord.

Guangzhou DSPPA Audio Co., Ltd.