


Unit : mm







Installation Manual:

1 ‖ The Ø20mm ØPVC Øtube Øfor ØAC Ø220V ØPower Øwires (3 X Ø2.0mm).

2 ‖ The tube for connecting vice-machine to master machine in the same lane (CAT5 network cables*2PCS, 2 * 0.5mm motor line*1PCS) .

3 ‖ TCP/IP ethernet cable for connecting access device to PC.

4 ▯ Control board .

5 ▯ Fixing the equipment with M12 X 90mm expansive bolt .

Mark:All wires extending out of the ground shall be no less than 2M.