W330

W330 leads a major leap into the era of dual-band WiFi6.

4K Ultra HD offers more surprises and possibilities. Say goodbye to blurry images and embrace the stunning clarity it offers. With W330, you can zoom in and ca pture distant details, revealing a whole new level of specificity. Prepare to be am azed as you witness the world like never before!

1. Specs



1	Metal-Aluminum Housing
2	Spotlight
3	IR LED
4	High Resolution Lens
5	Daylight Sensor
6	Antenna

7	Bracket
8	Built-in Speaker
9	Built-in Microphone



1	microSD Card Slot

2. Setup and Install

Set up the Camera

What’s in the Box

Note: The package content may vary and update with different version and platforms, please take the below information only for a reference. And the actual package content are subject to the latest information on the product selling page.

W330



W330*1



1m Network Cable*1




Quick Start Guide*1



Surveillance Sticker*1



Pack of Screws*1



Mounting Template *1



Wrench*1



4.5m Power Extension Cable *1




Power Adapter *1

Set up the Camera on the App


Before initial setup, follow the steps below to connect your camera:

1. Connect the camera to a LAN port on your router with an Ethernet cable.
2. Power on the camera with a power adapter.



For Reolink WiFi cameras with LAN ports but without voice prompt, here is a simple guide for you to get the initial setup done.

Step 1. Tap the icon on the top right corner.




Note: If you've enabled the **Add Device Automatically** option on the App's Settings page, you can tap this device on the **Devices** page and turn to **Step 3** directly.


Step 2. Scan the QR code on the back of the camera. You may tap **Light** to enable a flashlight when setting up the camera in a dark environment.

If the phone doesn't respond, please tap **Input UID/IP** and then manually type in the UID (16-digit characters under the QR code of the camera). Then tap **Next**.






Step 3. Create the password for your camera. Then tap **Next**.




Step 4. Name your camera. Then tap **Next**.




Step 5. Tap the WiFi network you want to join, and enter the password of the WiFi network.

Then tap **Save** to save the network configuration.



Step 6. Done! The initialization of your camera is finished.




Note: If this device can't connect to the WiFi after you remove the Ethernet cable, you can connect it to the router again and see if it can pass the WiFi test. Install the Camera


Please follow the steps below to install the camera.

Step 1. Drill holes in accordance with the mounting hole template.

NOTE: Use the drywall anchors included in the package if needed.



Step 2. Install the mount base with the mounting screws included in the package.




Notes:

Run the cable through the cable notch on the mount base.

As for the WiFi camera, it is recommended that the antennas be installed upwards or horizontally for better WiFi connection.

Step 3. To get the best field of view, loosen the adjustment knob on security mount and turn the camera.



Step 4. Stiffen the adjustment knob to lock the camera.

